















WIRED	Description	CODE Remote control without control box	CODE Remote control with control box	CODE Control box
	 <p><b>TWO BUTTONS</b>  <b>1:</b> Relax position opening  <b>2:</b> Relax position closing, lift function</p>	MOEC0093	/	/
		/	MOECCOS2636	EKOLOGIC according to the functions required
	 <p><b>TWO BUTTONS</b>  <b>1:</b> Relax position closing, lift function  <b>2:</b> Relax position opening</p>	MOEC0094	/	/
		/	/	/
	 <p><b>TWO BUTTONS</b>  <b>1:</b> Relax position opening  <b>2:</b> Relax position closing</p>	MOEC0095	/	/
		/	/	/
	 <p><b>TWO BUTTONS</b>  <b>1:</b> Relax position closing  <b>2:</b> Relax position opening</p>	MOEC0170	/	/
		/	MOECCOS2637	EKOLOGIC according to the functions required

WIRED	Description	CODE Remote control without control box	CODE Remote control with control box	CODE Control box
	 <p><b>FOUR BUTTONS</b>  <b>1:</b> Backrest opening  <b>2:</b> Backrest closing  <b>3:</b> Relax position opening  <b>4:</b> Relax position closing, lift function</p>	MOEC0096	/	/
		/	MOECCOS2641	EKOLOGIC according to the functions required
	 <p><b>FOUR BUTTONS</b>  <b>1:</b> Relax position opening  <b>2:</b> Relax position closing  <b>3:</b> Backrest opening  <b>4:</b> Backrest closing</p>	/	/	/
		/	MOECCOS2642	EKOLOGIC according to the functions required
	 <p><b>SIX BUTTONS</b>  <b>1:</b> Footrest opening  <b>2:</b> Footrest closing  <b>3:</b> Backrest opening  <b>4:</b> Backrest closing  <b>5:</b> Lift opening  <b>6:</b> Lift closing</p>	MOEC0097	/	/
		Long wiring MOEC0097		
		/	MOECCOS2643	EKOLOGIC according to the functions required

